



No	Phone	Type	Profile	BT Connection to the last connected phone after ignition is switched on	Init BT connection with device key	Phone's REDIAL activation	Activation phone's Voice Tags and using this function	It is possible to switch CarKit/private mode with BT device/phones keys	Software version
1	Nokia	6103	HF	✓	✓	✓	✓	✓	V04.90
2		6131	HF	✓	✓	✓	✓	✓	V03.70
3		6270	HF	✓	✓	✓	✓	✓	V3.66
4		6280	HF	✓	✓	✓	✓	✓	V4.25
5		6288	HF	✓	✓	✓	✓	✓	V05.92
6		6233	HF	✓	✓	✓	✓	✓	V03.70
7		6234	HF	✓	✓	✓	✓	✓	V3.50
8		E50	HF	✓	✓	✓	✓	✓	V06.27.1.0
9		E60	HF	✓	✓	✓	✓	✓	V.0610.02.15
10		E70	HF	✓	✓	✓	✓	✓	V1.0610.05.06
11		6310	HF	✓	✓	✓	✓	✓	V5.10
12		6310i	HF	✓	✓	✓	✓	✓	V5.51
13		9300	HF	✓	✓	✓	✗	✓	V4.53
14		9300i	HF	✓	✓	✓	✗	✓	V 05.50(00)
15		9500	HF	✓	✓	✓	✗	✓	V4.44
16		6600	HF	✓	✓	✓	✓	✓	V3.42.1
17		3230	HF	✓	✓	✓	✓	✓	V3.0505.2
18		5500	HF	✓	✓	✓	✓	✓	v 03.18
19		6680	HF	✓	✓	✓	✓	✓	V3.04.11
20		6681	HF	✓	✓	✓	✓	✓	V3.10.6
21		N70	HF	✓	✓	✓	✓	✓	V2.0536.02
22		N73	HF	✓	✓	✓	✓	✓	V2.0628.0.0.1
23		N90	HF	✓	✓	✓	✓	✓	V5.0607.7.3
24		N91	HF	✓	✓	✓	✓	✓	V1.11.003
25		N93	HF	✓	✓	✓	✓	✓	V10.0.025
26		N80	HF	✓	✓	✓	✓	✓	V 3.0617.0.6
27		6630	HF	✓	✓	✓	✓	✓	V2.39.152
28		3650	HF	✓	✓	✓	✓	✓	V4.13
29		6021	HF	✓	✓	✓	✓	✓	V03.87
30		6151	HF	✓	✓	✓	✓	✓	V03.56
31		6230	HF	✓	✓	✓	✓	✓	V5.40
32		6230i	HF	✓	✓	✓	✓	✓	V3.30
33		6820	HF	✓	✓	✓	✓	✓	V04.25
34		6820a	HF	✓	✓	✓	✓	✓	
35		6822	HF	✓	✓	✓	✓	✓	V4.48
36		7380	HF	✓	✓	✓	✓	✓	V03.80
37		7710	HF	✓	✓	✓	✓	✓	V03.04.2
38		8800	HF	✓	✓	✓	✓	✓	V03.60
39		8910	HF	✓	✓	✓	✓	✓	V04.02
40		N-GAGE	HF	✓	✓	✓	✓	✓	V3.30
41	Siemens	S55	HF	✓	✓	✓	✓	✓	SW:91
42		SX1	HF	✓	✓	✓	✓	✓	SW:14
43		S65	HF	✓	✓	✓	✗	✓	SW:25
44		SK65	HF	✓	✓	✓	✗	✓	SW:42
45		CX75	HF	✓	✓	✓	✗	✓	SW:05
46		M75	HF	✓	✓	✓	✗	✓	SW:05
47		S65v	HF	✓	✓	✓	✗	✓	SW:25
48		SP65	HF	✓	✓	✓	✗	✓	
49		EL71	HF	✓	✓	✓	✗	✓	SW:31

Bury GmbH & Co. KG, Robert-Koch-Str.1-7, D-32584 Löhne, Hotline: (0) 1805 842 468*, Faxline: (0) 1805 842 329* *(12ct/min),

E-mail: infoline@bury.com, Internet: www.bury.com

✓ working ✗ not working



No	Phone	Type	Profile	BT Connection to the last connected phone after ignition is switched on	Init BT connection with device key	Phone's REDIAL activation	Activation phone's Voice Tags and using this function	It is possible to switch CarKit/private mode with BT device/phones keys	Software version
50	Sony Ericsson	T68i	HF	✓	✓	✓	✓	✓	R5D007
51		T610	HF	✓	✓	✓	✓	✓	R3C002
52		T630	HF	✓	✓	✓	✓	✓	R7A011
53		K600i	HF	✓	✓	✓	✓	✓	R2AC001
54		K700i	HF	✓	✓	✓	✗	✓	R2AY004
55		S700i	HF	✓	✓	✓	✓	✓	R3C002
56		P910i	HF	✓	✓	✓	✗	✓	R4A006
57		K750i	HF	✓	✓	✓	✓	✓	R1A0044
58		W600i	HF	✓	✓	✓	✓	✓	R7B046
59		W700i	HF	✓	✓	✓	✓	✓	R1CA021
60		W800i	HF	✓	✓	✓	✓	✓	R1L002
61		W900i	HF	✓	✓	✓	✓	✓	R5BC004
62		D750i	HF	✓	✓	✓	✓	✓	R1N035
63		Z600	HF	✓	✓	✓	✓	✓	RE004
64		K610i	HF	✓	✓	✓	✓	✓	
65		V630i	HF	✓	✓	✓	✓	✓	
66		K800i	HF	✓	✓	✓	✓	✓	
67		K510i	HF	✓	✓	✓	✗	✓	R4CH003
68		Z520i	HF	✓	✓	✓	✗	✓	R3F015
69		Z1010	HF	✓	✓	✓	✓	✓	RG007
70		M600i	HF	✓	✓	✓	✗	✗	R1B01
71	V800	HF	✓	✓	✓	✓	✓	R1J002	
72	Motorola	A 835	HF	✓	✓	✓	✓	✓	TALINT_0_7232.07.02P
73		V500	HF	✓	✓	✓	✓	✓	TRIPLETS_G_0B09.10R_VR
74		V525	HF	✓	✓	✓	✓	✓	TRIPLETS_G0B09.1DR_VR
75		V550	HF	✓	✓	✓	✓	✓	R376_G_0E.65.26R
76		V551	HF	✓	✓	✓	✓	✓	R47_G08_17.OFR01
77		V600	HF	✓	✓	✓	✓	✓	TRIPLETS_G_0B09.38R
78		V620	HF	✓	✓	✓	✓	✓	R376_G_0E.65.25R
79		V3 RAZR	HF	✓	✓	✓	✓	✓	R374_G_0E40.3CR
80		E1 ROKR	HF	✓	✓	✓	✓	✓	R373_G_0E.30.42R
81		V3i	HF	✓	✓	✓	✓	✓	R479_G_08.B4.85R
82		SLVR V270	HF	✓	✓	✓	✓	✓	R3511_G_0A..50.1BR
83		V280	HF	✓	✓	✓	✓	✓	R3511_G_0A..50.22BR
84		L7	HF	✓	✓	✓	✓	✓	R4513_G_08.B7.54R_RB
85		C390	HF	✓	✓	✓	✓	✓	R368_G_0B_AQ0_05I
86		E398	HF	✓	✓	✓	✓	✓	-
87		E1070	HF	✓	✓	✓	✓	✓	R252211LD_U_85.97.C3P
88		U6	HF	✓	✓	✓	✓	✓	R478_G_08.83.76R_A
89	V635	HF	✓	✓	✓	✓	✓	R474_G_08.48.24R_A	
90	Toshiba	TS921	HF	✓	✓	✓	✗	✓	
91	Sharp	GX15	HF	✓	✓	✓	✗	✓	
92		GX25	HF	✓	✓	✓	✗	✓	
93		GX30i	HF	✓	✓	✓	✗	✓	

Bury GmbH & Co. KG, Robert-Koch-Str.1-7, D-32584 Löhne, Hotline: (0) 1805 842 468*, Faxline: (0) 1805 842 329* *(12ct/min),

E-mail: infoline@bury.com, Internet: www.bury.com

✓ working ✗ not working



No	Phone	Type	Profile	BT Connection to the last connected phone after ignition is switched on	Init BT connection with device key	Phone's REDIAL activation	Activation phone's Voice Tags and using this function	It is possible to switch CarKit/private mode with BT device/phones keys	Software version
94	Sda	I	HF	✓	✓	✓	✓	✓	V4.21.1088
95		Music	HF	✓	✓	✓	✓	✓	
96		II	HF	✓	✓	✓	✓	✓	
97	I-mate	SP3i	HF	✓	✓	✓	✓	✓	
98		JAM	HF	✓	✓	✓	✗	✓	V 1.03.00
99	SPV	C500	HF	✓	✓	✓	✗	✓	4.21.1088
100		M-500	HF	✓	✓	✓	✗	✓	1.05.10
101		M-1000	HS	✗	✗	✗	✗	✗	1.10.00
102		M-2000	HF	✓	✓	✓	✗	✓	
103	VPA	Compact	HF	✓	✓	✓	✗	✓	1.05.00
104		III	HF	✓	✓	✓	✗	✓	
105	MDA	II	HS	✗	✗	✗	✗	✗	4.20.0
106		Compact II	HF	✓	✓	✓	✓	✓	
107	Samsung	SGH-E720	HF	✓	✓	✓	✗	✓	
108		SGH-D307	HF	✓	✓	✓	✓	✓	
109		SGH-D500	HF	✓	✓	✓	✗	✓	
110		SGH-D520	HF	✓	✓	✓	✗	✓	1.0c
111		SHG-D600	HF	✓	✓	✓	✗	✓	
112		SHG-D900	HF	✓	✓	✓	✗	✓	D900E.05
113	Panasonic	X70	HF	✓	✓	✗	✗	✓	
114	Q-tek	9090	HF	✓	✓	✓	✗	✓	1.06.00
115		9100	HF	✓	✓	✓	✓	✓	1.6.7.1
116		2020	HS	✗	✗	✗	✗	✗	1.14.00
117	Xda	II s	HS	✓	✓	✓	✗	✓	
118		Mini S	HF	✓	✓	✓	✓	✓	01.09.10
119	BlacBerry	7290	HF	✓	✓	✓	✗	✓	V3.8.0.105
120		7100v	HF	✓	✓	✓	✗	✓	V4.0.2.16
121		8700g	HF	✓	✓	✓	✗	✓	V4.1.0258
122	Palm	Treo 650	HF	✓	✓	✓	✗	✓	
123		Treo 680	HF	✓	✓	✓	✗	✓	
124		Treo 750	HF	✓	✓	✓	✗	✓	
125	LG	KG810	HF	✓	✓	✓	✗	✓	

Bury GmbH & Co. KG, Robert-Koch-Str.1-7, D-32584 Löhne, Hotline: (0) 1805 842 468*, Faxline: (0) 1805 842 329* *(12ct/min),

E-mail: infoline@bury.com, Internet: www.bury.com

✓ working ✗ not working